



DuraPit Ball Pit Assembly Guide



Assembly Instructions

- **Step 1**: Unfold Ball Pit and lay flat on smooth surface.
- **Step 2**: Locate the transparent valve on the inside floor. Blow air into valve manually or use inflator to fully inflate.
- **Step 3**: Locate the transparent valve on the inside step. Blow air into valve manually or use inflator to fully inflate.
- **Step 4**: Locate the black valve on side and unscrew. Using compatible adaptor (not included) with inflator, fully inflate side walls.
- **Step 5**: Locate the transparent valve on the outside step. Blow air into valve manually or use inflator to fully inflate.
- **Step 6**: Use mesh cover to secure balls (purchased separately) in Ball Pit or to hold uninflated Ball Pit when not in use.

COMPONENT LIST

- (1) Vinyl Ball Pit
- (1) Mesh Cover

Step 2 & 3




Step 4





Step 5



Step 6



Sportime.com | Phone 800-283-5700