

# Snoezelen® WiFi Wireless Controller



This controller promotes inclusivity, cause and effect learning, choice, control and accessible learning. Allows the user to control the Snoezelen® equipment. It has been carefully designed to facilitate use for all, including individuals with fine/gross motor skill difficulties, visual impairment etc.

## FEATURES & BENEFITS

- 9 large, colorful buttons to wirelessly operate multiple products
- Designed with large buttons to help with eye-hand coordination, easy to see; good for table top, on the floor, on a lap; this is your portable controller
- Can activate individual products or all WiFi products in a room
- Pre-recorded multilingual words and sounds
- Adjustable timer helps facilitate the length of time for each color
- 9 external jack sockets to add your own switches
- Controller is only compatible with Snoezelen® WiFi products
- Rechargeable
- Easy to clean

## Can be used to control:

- Various Bubble Tubes and Waterless Rainbow Tubes (2123699, 2123695, 2123694, 2123704, 2123703, 2123710, 2140487, 2141362)
- Color Command Center (2120037)
- Color Catch Combo Panel (2120346)
- Double Bubble Bonanza Panel (2142249)
- Fireworks Extravaganza Panel (2119957)
- Sound to Sight Showtime (2120005)
- Multifinity Explorer Panel (2123511)
- Hip Hop Activity Panel (2138978)
- Interactive Aroma Panel (2120417)
- Additional controls on the underside including LCD display with pre-programmed functions

## MODELS

| MODEL                    | ITEM #  | PRODUCT DIMENSIONS |
|--------------------------|---------|--------------------|
| WiFi Wireless Controller | 2120147 | 14"Diam x 4¾"H     |