



Classroom Select® Y-Leg Computer Table

ASSEMBLY INSTRUCTIONS


Thank you for purchasing the Classroom Select® Y-Leg Computer Table from School Specialty®. Please review the enclosed packing list to ensure all components are included and read the instructions carefully before you begin assembly. If you find anything missing or have any questions now or after set-up, please contact Customer Care at 888.388.3224 or customer@schoolspecialty.com/contact-us-email.




PART AND TOOL LIST




Top
Quantity: 1




Leg Receiver
Quantity: 2




Leg Insert
Quantity: 2




Cable Tray
Quantity: 1



Crossbrace
Quantity: 1




Locking Caster
Quantity: 2



Non-Locking Caster
Quantity: 2




M6 x 45mm
Quantity: 8




M6 x 12mm
Quantity: 8


PART AND TOOL LIST




M6 Locking Nut
Quantity: 4



Caster Wrench
Quantity: 1




Allen Wrench
Quantity: 1



Glide
Quantity: 4


STEP 1

Attach Crossbrace to Leg Receivers using four M6 x 45mm screws and M6 lock nuts.




STEP 2

Place the top upside down on a stable, non-abrasive soft surface to avoid any scratching. Align Leg Receivers with inserts on underside of Top and fix to Top with four M6 x 45mm screws.




STEP 3

Connect Cable Tray to Leg Receivers with four M6 x 12mm screws.




STEP 4

Slide Leg Inserts into Leg Receivers and secure at desired table height with M6 x 12mm screws.




STEP 5

Insert Casters and tighten with Caster Wrench. Place both Locking Casters (D) in front. Note: Table can be assembled with a glide or caster option.



STEP 6

Flip table over.



DISCLAIMERS

Please review the enclosed packing list to ensure all components are included. Please read the instructions carefully before you begin assembly. If you find anything missing or have any questions now or after set-up, please contact Customer Care at 888.388.3224 or customercare.schoolspecialty.com/contact-us-email.

Heavy or large furniture may require two or more people for proper assembly. Improper assembly may void the warranty. Ensure all hardware is correctly installed and screws are fully tightened before use. Recheck and tighten screws at least once per year. Failure to assemble or secure parts properly may result in product failure or personal injury.

The products illustrated/photographed in this assembly instruction may vary slightly from the actual product.

Product Warranty: help.schoolspecialty.com/s/article/Product-Warranties