




Classroom Select® Advocate Series® Double Post Pedestal Leg Desk

ASSEMBLY INSTRUCTIONS

Thank you for purchasing the Classroom Select® Advocate Series® Double Post Pedestal Leg Desk from School Specialty®. Please review the enclosed packing list to ensure all components are included and read the instructions carefully before you begin assembly. If you find anything missing or have any questions now or after set-up, please contact Customer Care at 888.388.3224 or customercare.schoolspecialty.com/contact-us-email.





PART AND TOOL LIST






Table Top Quantity: 1




Leg Receiver Quantity: 2



Leg Insert Quantity: 2



Spanner Quantity: 1



Glide Quantity: 4




Wood Screw Quantity: 12



M6x12mm Allen Screw Quantity: 12



Lock Washer Quantity: 12




Allen Wrench Quantity: 1




STEP 1

Place the top upside down on a stable, non-abrasive soft surface to avoid any scratching. Attach both Leg Receivers to underside of table top using predrilled holes as a guide for placement. Each Receiver will require six wood screws. Drive screws with an electric drill and tighten until snug.



STEP 2


Attach Spanner to Leg Receivers with four M6 x 12mm screws and lock washers.






STEP 3

Slide Leg Inserts into Leg Receivers. At preferred leg height hold Inserts in place with four M6 x 12mm screws and lock washers per Insert fastened through Receivers. Make height adjustments as needed then



Screw in all four glides to bottom of Leg Inserts (2 per leg).





DISCLAIMERS

Please review the enclosed packing list to ensure all components are included. Please read the instructions carefully before you begin assembly. If you find anything missing or have any questions now or after set-up, please contact Customer Care at 888.388.3224 or customercare.schoolspecialty.com/contact-us-email.

Heavy or large furniture may require two or more people for proper assembly. Improper assembly may void the warranty. Ensure all hardware is correctly installed and screws are fully tightened before use. Recheck and tighten screws at least once per year. Failure to assemble or secure parts properly may result in product failure or personal injury.

The products illustrated/photographed in this assembly instruction may vary slightly from the actual product.

Product Warranty: help.schoolspecialty.com/s/article/Product-Warranties