



Classroom Select® Inspo® Stacking Desk

ASSEMBLY INSTRUCTIONS


Thank you for purchasing Classroom Select® Inspo® Stacking Desk from School Specialty®. Please review the enclosed packing list to ensure all components are included and read the instructions carefully before you begin assembly. If you find anything missing or have any questions now or after set-up, please contact Customer Care at 888.388.3224 or customercare.schoolspecialty.com/contact-us-email.



PART AND TOOLS LIST




Top 20x27 Stack / Combine 2
Quantity: 1



Leg insert with Caster
Quantity: 2




Leg insert with Glide
Quantity: 2



Serrated Head Screw
Quantity: 8

STEP 1

Place the top upside down on a stable, non-abrasive soft surface to avoid any scratching. Insert the legs into the frame. After setting the leg height, leave the leg insert screw $\frac{1}{4}$ turn loose, flip the desk over, and make sure the unit is level. Then turn $\frac{1}{4}$ turn and tighten the screws, so the inserts are not wobbly.



DISCLAIMERS

Please review the enclosed packing list to ensure all components are included. Please read the instructions carefully before you begin assembly. If you find anything missing or have any questions now or after set-up, please contact Customer Care at 888.388.3224 or customercare.schoolspecialty.com/contact-us-email.

Heavy or large furniture may require two or more people for proper assembly. Improper assembly may void the warranty. Ensure all hardware is correctly installed and screws are fully tightened before use. Recheck and tighten screws at least once per year. Failure to assemble or secure parts properly may result in product failure or personal injury.

The products illustrated/photographed in this assembly instruction may vary slightly from the actual product.

Product Warranty: help.schoolspecialty.com/s/article/Product-Warranties