



Classroom Select® Activity Table with Pedestal Legs

ASSEMBLY INSTRUCTIONS


Thank you for purchasing Classroom Select® Activity Tables with Pedestal Legs from School Specialty®. Please review the enclosed packing list to ensure all components are included and read the instructions carefully before you begin assembly. If you find anything missing or have any questions now or after setup, please contact Customer Care at 888.388.3224 or customercare.schoolspecialty.com/contact-us-email



PART AND TOOLS LIST




Tabletop Rectangle
Quantity: 1




Activity Table Pedestal Leg Insert with Glide
Quantity: 2



Activity Table Pedestal Leg Upper
Quantity: 2




Screw, m8-1_25mmx45mm
Quantity: 4



Screw, m6-1mmx12mm,
Quantity: 4


STEP 1

In this installation step, begin by positioning the pedestal leg supports onto the base frame. Place the table top upside down on a stable, non-abrasive soft surface to avoid any scratching. Align the pre-drilled holes on both components to ensure a precise fit. Secure the legs in place by inserting the bolts through the designated holes and tightening them firmly. The detailed views highlight the proper alignment and attachment points. Ensure all bolts are fully tightened to provide a stable and secure structure before proceeding to the next step.



STEP 2

Align the upper support posts with the lower legs, ensuring the holes match. Slide the upper support into place. Insert and tighten the screws or bolts securely. Attach additional components as shown. Check alignment before proceeding. After setting the leg height, leave the leg insert screw 1/4 turn loose, flip the desk over, and make sure the unit is level. Then turn 1/4 turn and tighten the screws, so the inserts are not wobbly.



DISCLAIMERS

Please review the enclosed packing list to ensure all components are included. Please read the instructions carefully before you begin assembly. If you find anything missing or have any questions now or after set-up, please contact Customer Care at 888.388.3224 or customercare.schoolspecialty.com/contact-us-email.

Heavy or large furniture may require two or more people for proper assembly. Improper assembly may void the warranty. Ensure all hardware is correctly installed and screws are fully tightened before use. Recheck and tighten screws at least once per year. Failure to assemble or secure parts properly may result in product failure or personal injury.

The products illustrated/photographed in this assembly instruction may vary slightly from the actual product.

Product Warranty: help.schoolspecialty.com/s/article/Product-Warranties