ADULT ASSEMBLY REQUIRED Model Numbers: 2161350, 2161354, 2161355, 2161362

Outdoor Rectangular Tables

BIRD • IN • HAND Woodworks, Inc.

Lancaster, Pennsylvania

Product Guide - General Instructions and Information

Customer Service:

P.O. Box 1579 Appleton, WI 54912-1579 Phone: 1-888-388-3224 Customer Care Website:

https://help.schoolspecialty.com/s/

Warning:

This product is for children. Supervision is required at all times.

Warning:

Manufacturer is not responsible for modifications made to our products by customers.

Cleaning:


Use a mild soap and water solution. Be sure to wipe all water from the surface.

Important:

Do not discard these instructions. Keep for future reference.

Table Assembly: (Two people are recommended)

- Make sure to align the end panels properly so that the holes in the top and shelf frames match the end panel.
- 2. Use a power screwdriver to drive the screws completely until tight. DO NOT OVERTIGHTEN THE SCREWS. Overtightening the screws can cause them to strip out, which will affect the stability of the table.
- 3. Start by attaching the side panels to the top frame. Use the 1 1/2" long screws as shown below. Use the 1 1/4" long screws to attach the side panel cleats to the top as shown below.




ADULT ASSEMBLY REQUIRED BIRD-IN-HAND

Product Guide - General Instructions and Information

A member of the School Specialty Family

Table Assembly: (Two people are recommended)

Carefully lower the assembled shelf between the side panels until the end holes are aligned with the holes on the side panel. Attach the shelf using the 1 1/2" long stainless steel screws.



One of the many benefits of HDPE is that it is water resistant and very easy to clean. HDPE can be cleaned regularly using a standard soap and water solution.

- Using soap and fresh water, wipe down the material with a soft clean towel.
- If there is debris on the surface, spray off the affected area first with a hose.
- If necessary, remove excess dirt and debris by scrubbing with a soft brush or sponge.
- Allow the material to air dry or use a soft towel.
- For tougher soiled areas, use 1/2 cup of household detergent and 1 gallon of water to break down the stains.
- A pressure washer with no greater than 2000 psi may be used to remove dirt, dust, or other types of airborne particulates. Do not direct the spray close to the furniture. (less than 8")
- Avoid using chemical cleaners, sprays and hard scrubbers which can be abrasive to the material