


# Classroom Select® Neolink® Upholstered Media Wall


## ASSEMBLY INSTRUCTIONS

Thank you for purchasing the Classroom Select® Neolink® Upholstered Media Wall from School Specialty®. Please review the enclosed packing list to ensure all components are included and read the instructions carefully before you begin assembly. If you find anything missing or have any questions now or after set-up, please contact Customer Care at 888.388.3224 or [customer@schoolspecialty.com](mailto:customer@schoolspecialty.com)/contact-us-email.




## PART AND TOOL LIST


---




P1: Media Wall  
Quantity: 1



P2: Table Top  
Quantity: 1




P3: Pedestal Base  
Quantity: 1




P4: Stretcher Bar  
Quantity: 2



A: Wood Screw - Wall to Top  
( $\frac{1}{4}$ " x  $\frac{5}{8}$ ")  
Quantity: 14



B: Wood Screw - Base to Top  
(#10 x 1")  
Quantity: 12




C: Wood Screw - Stretcher Bar  
( $\frac{1}{4}$ " x 1- $\frac{1}{2}$ ")  
Quantity: 6

\*\*Extra Screws  
May be Provided\*\*


## STEP 1

Attach Base to underside of Top with 1" wood screws. If stretcher bars are included (112" tops only), attach both to top with three 1-½" wood screws each.



## STEP 2

With Media Wall standing upright, lift top with two or more people and set on top of wall brackets. Ensure table is centered with wall then drive 5/8" screws from underneath the brackets into top.



## DISCLAIMERS

---

Please review the enclosed packing list to ensure all components are included. Please read the instructions carefully before you begin assembly. If you find anything missing or have any questions now or after set-up, please contact Customer Care at 888.388.3224 or [customercare.schoolspecialty.com/contact-us-email](mailto:customercare.schoolspecialty.com/contact-us-email).

Heavy or large furniture may require two or more people for proper assembly. Improper assembly may void the warranty. Ensure all hardware is correctly installed and screws are fully tightened before use. Recheck and tighten screws at least once per year. Failure to assemble or secure parts properly may result in product failure or personal injury.

The products illustrated/photographed in this assembly instruction may vary slightly from the actual product.

**Product Warranty:** [help.schoolspecialty.com/s/article/Product-Warranties](https://help.schoolspecialty.com/s/article/Product-Warranties)